

# **Guide for Installation and Enrollment**

### Precautions for FaceStation F2 installation



Keep out of direct sunlight.



Install it following the optimal height: FSF2-ODB: 124 cm | FSF2-AB,DB: 127 cm



Operate it within -20°C-50°C (-4°F-122°F).



Do not install it in a dark place.



Do not install where the subject is backlit.

#### How to enroll Visual Face

FaceStation F2 uses Visual Face taken with a visual camera as a means of authentication. Visual Face is an authentication method that distinguishes it from face templates used in face recognition terminals, allowing users to enroll faces in a variety of convenient ways.

Enroll Visual Face on FaceStation F2

Enroll Visual Face on BioStar 2

Enroll Visual Face

Girectly on FaceStation F2.

Take a picture using FaceStation F2

or upload an image file.

Enroll Visual Face on BioStar 2

Take a picture using a mobile device by following the link sent from BioStar 2.


Note: · Activate the BioStar 2 Cloud before enrolling Visual Face using a mobile device. It requires the Standard or higher license to use this feature.

- If the Visual Face enrollment using a mobile device fails, enroll directly on the FaceStation F2.
- The Visual Face enrollment link sent is only valid for 24 hours.

# How to take a picture for Visual Face

Refer to the BioStar 2 help manual to learn more about each method.

To use Visual Face correctly, take a picture by following instructions below.



Note: • The Visual Face data of FaceStation F2 are not compatible with face templates of FaceStation 2 or FaceLite.

## Suprema Inc.

17F Parkview Tower, 248, Jeongjail-ro, Bundang-gu, Seongnam-si, Gyeonggi-do, 13554, Republic of Korea T +82 31 783 4502 www.supremainc.com